







OWNER'S MANUAL

MT-EL223GX



- If you need to mount the flashlight onto a firearm, make sure the firearm is unloaded before installation
- Always use safe handling practices at all times. Do not operate the flashlight if the unit is defective.
- Avoid direct eye contact with the flashlight beam and its potentially bright reflection as this may cause serious eye injury.
- Do not direct the flashlight at any aircraft, public transportation, or other objects of safety concern. This is very dangerous and may be considered a felony.
- Ensure the flashlight cannot be turned on when stored or being transported. If the flashlight is activated while in a case, container, etc. it can become a fire hazard and cause damages.
 - Examine the battery quality and appearance before use and make sure no battery leakage or deformation is present. Dispose appropriately when necessary and replace with a new battery.
 - In general, batteries are pre-charged by the manufacturer and cannot be recharged. Recharging can cause battery leakage and in some cases, cause a high-pressure rupture.
 - Inadvertent charging can occur if a battery is installed backwards.
- Remove battery from the flashlight if storing away for a prolonged period of time. Leaving the battery in without use for a prolonged period may cause damages. Keep battery in a cool and dry environment.
- Do not use a rechargeable batteries unless explicitly specified in this manual.
- Never deliberately short circuit the battery. Prolonged short circuiting will cause the battery to drain and potentially result in a significant increase in temperature.
- Do not transport the flashlight with the battery installed enclosed in an environment that may experience high temperatures and or is not well ventilated, such as, the inside of a car trunk.
- Keep battery compartment clean from debris.
- Lithium batteries can explode and cause harm if disassembled, shorted, recharged, exposed to water, fire, or high temperatures. Do not place loose batteries in pockets, purse, etc.
- Do not mix new and old batteries together and or use different battery types together
- Do not store batteries with hazardous or combustible materials. Store in a cool, dry, ventilated
- Follow all applicable laws and regulations for disposal.

Length 2.13" (54.1mm)	MT-EL223GX			
Height 4.09" (103.9mm) Weight with 8attery Operating Time Weight with 6.6oz (187.1g) Bulb Type 23mm IRB* with CREE LED Woltage 6V Wide Angled Flood Rated to IPX7 Standards; Will Perform at 1 Meter Depth for 30 Minutes High - 3 Hours / Low - 24 Hours	Specifications	Length	2.13" (54.1mm)	
Weight with Battery Bulb Type 23mm IRB* with CREE LED Voltage 6V Max. 400 lumen Vultage Focus Wide Angled Flood Waterproof Panalards; Will Perform at 1 Meter Depth for 30 Minutes Battery Operating Time Weight with 6.6oz (187.1g) Bulb Type 23mm IRB* with CREE LED Water LED Water LED Wide Angled Flood Will Perform at 1 Meter Depth for 30 Minutes Low - 24 Hours		Width	1.38" (35.1mm)	
Battery Bulb Type 23mm IRB* with CREE LED Voltage 6V Max. Output 400 lumen Wide Angled Flood Rated to IPX7 Standards; Will Perform at 1 Meter Depth for 30 Minutes Battery Operating Time High - 3 Hours / Low - 24 Hours		Height	4.09" (103.9mm)	
Pour Process of the P		Weight with Battery	6.6oz (187.1g)	
Focus Flood Rated to IPX7 Standards; Will Perform at 1 Meter Depth for 30 Minutes Battery Operating Time High - 3 Hours / Low - 24 Hours		Bulb Type	23mm IRB* with CREE LED	
Focus Flood Rated to IPX7 Standards; Will Perform at 1 Meter Depth for 30 Minutes Battery Operating Time High - 3 Hours / Low - 24 Hours		Voltage	6V	
Focus Flood Rated to IPX7 Standards; Will Perform at 1 Meter Depth for 30 Minutes Battery Operating Time High - 3 Hours / Low - 24 Hours			400 lumen	
Waterproof Waterproof Water Depth for 30 Minutes Battery Operating Time Standards; Will Perform at 1 Meter Depth for 30 Minutes High - 3 Hours / Low - 24 Hours		Focus		
Operating Time Low - 24 Hours		Waterproof	Standards; Will Perform at 1 Meter Depth for	
Quantity/ Battery 2 x CR123A Pressure Switch N/A		Operating	High - 3 Hours / Low - 24 Hours	
Pressure N/A Switch	Accessories		2 x CR123A	
			N/A	

Component Illustration



*IRB - Integrated Reflector and Bulb







Installation & Operation

Battery Installation

To remove the grip light's end cap, using a coin, turn the end cap 90 degrees or a quarter turn to unlock it. The End Cap can be turned in either direction.

Insert the two included CR123A batteries in the correct orientation depicted on the inside of the battery compartment.

Replace the end cap so that the spring-sided face makes contact with the CR123A battery that is showing its negative side outward in the battery compartment. (Fig. 1-2)

Using a coin, push and hold down the end cap and turn it 90 degrees or a quarter turn to lock it back in place.

Grip Light Installation

Using the included Torx wrench, loosen the side locking plate screw by turning it counterclockwise enough for the mounting base to seat evenly onto your firearm's Picatinny rail and with its squared recoil stop fitting into your preferred slot along the rail. (Fig. 2-1)

Once seated evenly, retighten the side locking plate screw by turning the clockwise until securely tightened. Recommended torque value: 35 inch-lb. (Fig. 2-2)

Grip Light Operation:

Rear Main Power Button (Fig. 3-1)

a. Momentary/Constant-On/Off Operation (For



Power Button



Control Pad-





Fig. 3-2



operation of full 400 Lumen output)

i. Momentary-On/Off

Slightly pressing and holding down the rear main power button will turn the grip light on for the duration in which it is held down

ii. Constant-On/Off

Fully pressing the rear main power button down until it clicks will turn the grip light on until it is fully pressed again until it clicks and turn off

Strobe (Fig. 3-2) a. The Ambidextrous toggles on the left and right side of the grip light control the grip light's strobe function. The strobe operates at the full 400 lumen output

i. Momentary-On/Off

Pressing and holding down either the left or right side toggle will turn strobe on for the duration in which it is held down

Front Lumen Control Pad-Dimming (Fig. 3-3)

a. After putting the grip light into constant-on using the rear main power button, pressing and holding down the front lumen control pad will slowly begin dimming the lumen output from 400 and stopping at 20

b. Letting go of the lumen control pad at any time during its dimming will stop you at that exact adjusted output along its 400 to 20 lumen scale.

Note: Activating strobe at this time will still output at the grip light's max 400 lumen, but will return to the adjusted lumen output upon releasing the strobe toggle. Turning off the grip light using the rear main power button will reset the grip light back to its default max 400 lumen output.

Maintenance

- Maintain the flashlight's polymer surface removing any dirt or sand with a simple wipe down.
- Do not attempt to lubricate any part of the flashlight with the exception of the o-ring used to seal the end cap.
- Do not disassemble the flashlight any further than when replacing the battery.
 Any such actions will void the warranty.

The Best Never Rest Warranty - Lifetime

Leapers, Inc. warrants that all UTG & UTG PRO products conform to published specifications and are free from defects in material and workmanship. We will repair or replace defective products for the duration of the product's life span. Our dedicated and professional in-house customer service team will go above and beyond to make things right and provide the best in-class customer service experience you expect to receive. Our warranty does not extend to products damaged from misuse, accidental damage, negligence, natural disasters/accidents, or unauthorized repair or alteration. For warranty service, please submit your inquiry by visiting our customer service page on our website at www.leapers.com or give us a call at 734-542-1500. A Return Authorization Number (RMA) must be assigned before returning any products for warranty service.

Disclaimer and Limitation of Liability

Leapers is pleased to offer suggestions of the use of its products, however Leapers neither assumes responsibility for any omissions or errors nor assumes liability for any damages that result from the use of its products in accordance with information provided by Leapers, whether verbal or written.

EXCEPT FOR THE EXPRESS WRITTEN WARRANTY SPECIFICALLY SET FORTH ABOVE, ALL EXPRESS AND IMPLIED REPRESENTATIONS AND WARRANTIES ARE HEREBY DISCLAIMED, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY, NON-INTERFERENCE, FITNESS FOR A PARTICULAR PURPOSE, NON-INFRINGEMENT, OR WARRANTY OF ACCURACY OF ANY INFORMATION PROVIDED WHETHER WRITTEN OR ORAL. ALL WARRANTIES ARISING FROM ANY COURSE OF DEALING, LAW, USAGE OR TRADE PRACTICE ARE HEREBY EXPRESSLY EXCLUDED TO THE EXTENT ALLOWED BY LAW. TO THE EXTENT AN IMPLIED WARRANTY CANNOT BE EXCLUDED, SUCH WARRANTY IS LIMITED IN DURATION TO ONE YEAR. SOME STATES OR JURISDICTIONS DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS, SO THE ABOVE LIMITATION MAY NOT APPLY TO YOU.

UNDER NO CIRCUMSTANCES IS LEAPERS, OR ITS SUPPLIERS OR RESELLERS LIABLE FOR ANY OF THE FOLLOWING EVEN IF INFORMED OF THEIR POSSIBILITY: 1) THIRD PARTY CLAIMS AGAINST YOU FOR DAMAGES; 2) SPECIAL, INCIDENTAL, OR INDIRECT DAMAGES OR FOR ANY ECONOMIC CONSEQUENTIAL DAMAGES; 03: 3) LOST PROFITS, BUSINESS REVENUE, GOODWILL, OR ANTICIPATED SAVINGS. SOME STATES OR JURISDICTIONS DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATION OR EXCLUSION MAY NOT APPLYTO YOU.