







If you need to mount the flashlight onto a firearm, make sure firearm is not loaded before installation. Remove magazine and examine chamber. Use safe handling procedures at all times.

Tactical flashlights produce substantial heat during operation. Do not leave activated flashlight unattended. Do not set activated flashlight face down. Do not place activated flashlight against combustible material or material that could be damaged by heat. Do not hold bezel or lens of activated flashlight against any portion of human body. Keep away from children.

Ensure that the flashlight cannot be turned on when stored or being transported. If the lamp is activated while in a case or any container, the lamp could overheat and cause damage to surrounding materials.

Examine battery quality and appearance before use each time and make sure that there is no leaking or any deformation. Dispose appropriately if there is a problem.

The batteries are pre-charged by the manufacturer, and cannot be recharged. Recharging can cause battery leakage or, in some cases, high-pressure rupture. Inadvertent charging can occur if a battery is installed backwards.

Do not use rechargeable batteries in the light, unless the product specifications clearly states that re-chargeable batteries can be used.

Install batteries by aligning the + and – signs marked on the battery with the + and – signs marked on the battery chamber in the light.

Turn off the light when not in use to conserve battery power.

Make sure to turn off the light or disconnect the pressure switch before inspecting bulb and battery if the light cannot be turned on.

Keep batteries cool and dry. Always remove batteries from light after use. Leaving battery in the light without use for long period of time may cause damage or danger.

Always replace batteries with the exact type and size specified for the light.

Always replace the whole set of batteries at the same time. Never mix new and used batteries in the same light.

Never deliberately short circuit batteries. Prolonged short circuit will cause the battery to lose energy and result in significant temperature increase.

Keep battery compartment clean and keep any metallic object away from the battery.

Lithium batteries can explode or cause burns if disassembled, shorted, recharged, exposed to water, fire, or high temperatures. Do not place loose batteries in a pocket, purse, or other containiner containing metal objects. Do not mix new with used batteries or mix required batteries with other types of battery. Do not store batteries with hazardous or combustible materials. Store in cool, dry, ventilated area. Follow applicable laws and regulations for disposal.

> Do not use rechargeable batteries unless explicitly specified in this manual Using rechargeable batteries may result in Bulb/IRB\* damage.

LT-ELP120R		
openiiraiiuis	Length	2.98" (75.8mm)
	Width	1.12" (28.5mm)
	Height	1.13" (28.7mm)
	Weight with Battery	2.6oz (73g)
	Bulb Type	20mm IRB with CREE LED
	Max. Output	200 Lumen
	Focus	Preset Flood
	Waterproof	Rated to IPX7 Standards; Will Perform at 1 Meter Depth for 30 Minutes
	Battery Operating Time	1 Hour
	Quantity/ Battery	1 x 3N
	Pressure Switch	N/A

**Component Illustration** 

Ambidextrous Momentary/ Constant On/Off Toggle Switches



\*IRB - Integrated Reflector and Bulb



### Installation & Operation Battery Installation

- Turn the flashlight's bezel head counterclockwise to remove it and gain access to the battery compartment. (Fig. 1-1)
- Insert the CŔ2 battery with its + side facing up into the battery compartment. (Fig. 1-2)
   Reinstall the bezel bead by turning it clockwise

Reinstall the bezel head by turning it clockwise until securely tightened.

> Make Sure the Firearm is Unloaded. Follow All Basic Rules of Firearms Safety

## INSTALLING THE FLASHLIGHT:







Fig. 2-3

the slot's forward facing wall. (Fig. 2-2) Retighten the side locking plate screw by turning it clockwise with the included tool until securely tightened. Recommended torque value: 12 in-lb. (Fig. 2-3)

#### ON/OFF OPERATIONS: Constant On/Off

2.

Pushing the upper ambidextrous toggle switch upward once will keep the flashlight on. Another push will turn the flashlight off. (Fig. 3-1)

### Momentary On/Off

Pushing and holding the lower ambidextrous toggle switch will turn the flashlight on for the duration in which you hold it down for. (Fig. 3-2)

Fig. 2-2

Fig. 1-2

Fig. 2-1

#### Maintenance

- Maintain the metal surface of the flashlight by removing any dirt or sand with a soft brush to avoid scratching the finish.
- Store the flashlight in a cool dry place when not in use. Be careful to avoid contact with acid, alkaline or corrosive chemicals.
- 3. Do not store the flashlight in areas of extreme high or low temperatures.
- Outside of lightly lubricating the battery compartment cap o-ring, do not attempt to lubricate any
  other part of the flashlight.
- Do not disassemble the flashlight any further than what is explicitly mentioned in this owner's manual.

## The Best Never Rest Warranty - Lifetime

Leapers, Inc. warrants that all UTG & UTG PRO products conform to published specifications and are free from defects in material and workmanship. We will repair or replace defective products for the duration of the products life span. Our dedicated and professional in-house customer service team will go above and beyond to make things right and provide the best in-class customer service experience you expect to receive. Our warranty does not extend to products damaged from misuse, accidental damage, negligence, natural disasters/accidents, or unauthorized repair or alteration. For warranty service, please submit your inquiry by visiting our customer service page on our website at www.leapers.com or give us a call at 734-542-1500. A Return Authorization Number (RMA) must be assigned before returning any products for warranty service.

# **Disclaimer and Limitation of Liability**

Leapers is pleased to offer suggestions of the use of its products, however Leapers neither assumes responsibility for any omissions or errors nor assumes liability for any damages that result from the use of its products in accordance with information provided by Leapers, whether verbal or written.

EXCEPT FOR THE EXPRESS WRITTEN WARRANTY SPECIFICALLY SET FORTH ABOVE, ALL EXPRESS AND IMPLIED REPRESENTATIONS AND WARRANTIES ARE HEREBY DISCLAIMED, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY, NON-INTERFERENCE, FITNESS FOR A PARTICULAR PURPOSE, NON-INFRINCEMENT, OR WARRANTY OF ACCURACY OF ANY INFORMATION PROVIDED WHETHER WRITTEN OR OR CAL. ALL WARRANTIES ARISING FROM ANY COURSE OF DEALING, LAW, USAGE OR TRADE PRACTICE ARE HEREBY EXPRESSIVE EXCLUDED TO THE EXTENT ALLOWED BY LAW. TO THE EXTENT AN IMPLIED WARRANTY CANNOT BE EXCLUDED, SUCH WARRANTY IS LIMITED IN DURATION TO ONE YEAR. SOME STATES OR JURISDICTIONS DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS, SO THE ABOVE LIMITATION MAY NOT APPLY TO YOU.

UNDER NO CIRCUMSTANCES IS LEAPERS, OR ITS SUPPLIERS OR RESELLERS LIABLE FOR ANY OF THE FOLLOWING EVEN IF INFORMED OF THEIR POSSIBILITY: 1) THIRD PARTY CLAIMS AGAINST YOU FOR DAMAGES; 2) SPECIAL, INCIDENTAL, OR INDIRECT DAMAGES OR FOR ANY ECONOMIC CONSEQUENTIAL DAMAGES; OR 3) LOST PROFITS, BUSINESS REVENUE, GOODWILL, OR ANTICIPATED SAVINGS, SOME STATES OR JURISDICTIONS DO NOTALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATION OR EXCLUSION MAY NOT APPLY TO YOU.